

Power Steering System Flushing

Material

Item	Specification
MERCON® V Automatic Transmission Fluid XT-5-QM (or XT-5-QMC) (US); CXT-5-LM12 (Canada)	MERCON® V

NOTICE: Do not mix fluid types. Any mixture or any unapproved fluid may lead to seal deterioration and leaks. A leak may ultimately cause loss of fluid, which may result in a loss of power steering assist.

1. Remove the power steering fluid reservoir cap.
2. Using a suitable suction device, remove the power steering fluid from the reservoir.
3. Release the clamp and disconnect the return hose from the reservoir.
 - Remove the clamp from the hose and allow the remaining fluid to drain out of the reservoir.
4. Plug the power steering fluid reservoir inlet port.
5. Attach an extension hose to the return hose.
6. **NOTE:** Do not reuse the power steering fluid that has been flushed from the power steering system.

Place the open end of the extension hose into a suitable container.

7. If equipped with Hydro-Boost®, apply the brake pedal 4 times.
8. **NOTE:** Do not overfill the reservoir.

Fill the reservoir as needed with the specified fluid.

9. **NOTICE:** Do not allow the power steering pump to run completely dry of power steering fluid. Damage to the power steering pump may occur.

Start the engine while simultaneously turning the steering wheel to lock and then immediately turn the ignition switch to the OFF position.

10. **NOTE:** Avoid turning the steering wheel without the engine running as this may cause air to be pulled into the steering gear.

NOTE: Do not overfill the reservoir.

Fill the reservoir as needed with the specified fluid.

11. Repeat Steps 8 and 9, turning the steering wheel in the opposite direction each time, until the fluid exiting the power steering fluid return hose is clean and clear of foreign material.
12. Remove the extension hose from the return hose.
13. Remove the plug from the fluid reservoir inlet port.
14. Install the clamp and connect the power steering return hose to the reservoir.

15. **NOTE:** It is necessary to correctly fill the power steering system to remove any trapped air and completely fill the power steering system components.

If, after correctly filling the power steering system, there is power steering noise accompanied by evidence of aerated fluid and there are no fluid leaks, it may be necessary to purge the power steering system. For additional information, refer to [Power Steering System Purging](#) in this section.

Fill the power steering system. For additional information, refer to [Power Steering System Filling](#) in this section.
