

## Information And Message Center

The message center is a Vacuum Fluorescent (VF), fixed format display that is integrated into the center of the Instrument Cluster (IC). The message center functions are controlled by the message center switches. The message center displays important vehicle information by constantly monitoring different vehicle systems. The message center displays a warning message pertaining to the system in which a fault has been detected. Refer to the Owner's Literature for operating instructions.

The message center provides the following features:

- Information displays
- Setup displays
- Warning messages
- System check messages

The message center information can be selected through a set of 3 buttons:

- SET
- INFO
- RESET

### Information Mode

The information displays are non-timed modes. The selected mode remains on until the driver presses a message center button to change the mode or it is overridden by another mode. The information display modes are:

- Trip/total odometer
- Trip odometer
- Distance To Empty (DTE)
- Average fuel economy
- Fuel used
- Instantaneous fuel economy
- Trip elapsed drive time
- Average speed
- Blank display

### Setup Mode

The setup mode provides a list of items that can be configured by the driver. The setup modes are:

- SYSTEM CHECK
- COLOR SELECTION
- UNITS (English/Metric)
- DISPLAY MODE (Single/Dual)
- LANGUAGES

### Warnings Mode

A single chime sounds when a warning message is displayed. The warning messages display once whenever the ignition switch is turned to the ON position or a fault occurs in a system.

The warning messages are:

- DRIVER DOOR AJAR
- PASSENGER DOOR AJAR
- TRUNK AJAR
- CHECK CHARGING SYSTEM
- CHECK FUEL CAP
- CHECK TRAC CONTROL
- LOW BRAKE FLUID LEVEL
- BRAKE SYSTEM FAILURE
- PARK BRAKE ON
- LOW FUEL LEVEL
- LOW OIL PRESSURE
- TURN SIGNAL ON

### **System Check**

Selecting this function from the SETUP menu causes the message center to cycle through each of the systems being monitored. For each of the monitored systems, the message center indicates either an OK message or a warning message for 2 to 4 seconds. The sequence of the system check report is as follows:

- OIL PRESSURE OK
- CHARGING SYSTEM OK
- DRIVERS DOOR CLOSED
- PASSENGER DOOR CLOSED
- TRUNK CLOSED
- BRAKE SYSTEM OK
- TRAC CONTROL OK
- FUEL CAP OK
- FUEL LEVEL OK
- XXX MILES TO EMPTY

### **Performance Mode Configuration (Shelby GT 500 Only)**

The message center provides the ability to configure the performance shift warning indicator and the performance shift warning chime features independent of each other. The 2 configurable items for each feature are the feature on/off and the shift points (engine rpm). Refer to [Message Center Configuration](#) in this section for configuring these 2 items.

---