



## Convertible Top

### Special Tool(s)

 <p>ST1137-A</p>	<p>73III Automotive Meter 105-R0057 or equivalent</p>
 <p>ST2834-A</p>	<p>Vehicle Communication Module (VCM) and Integrated Diagnostic System (IDS) software with appropriate hardware, or equivalent scan tool</p>

### Material

Item	Specification
<p>MERCON® V Automatic Transmission Fluid XT-5-QM (or XT-5-QMC) (US); CXT-5-LM12 (Canada)</p>	<p>MERCON® V</p>

### Principles of Operation

**NOTE:** The Smart Junction Box (SJB) may also be identified as the Generic Electronic Module (GEM).

The convertible top system is controlled by the **SJB**. When the convertible top switch is activated, the **SJB** commands the front and rear windows to the full down position. When the **SJB** detects that the LH and RH rear window motors are in the full downward position, it will command the appropriate relay to close in order to raise or lower the convertible top. If the **SJB** does not detect a full down signal from the LH and RH rear window motors, the convertible top operation will be disabled.

The convertible top assembly is a floating frame, Z-fold design. The main pivot brackets are attached to the body, and the convertible top frame side rails expand or fold when the convertible top is raised or lowered. The LH and RH stay pads are attached to the convertible top frame bows, and provide the main source of tension for the convertible top material. When the convertible top is in the full down position, it is stored in the compartment behind the rear seat backrest. When the convertible top is in the full up position, the body provides a stop which the convertible top frame No. 5 bow contacts to provide a weather seal for the convertible top against the body.

The convertible top hydraulic system uses a reversible hydraulic pump and motor assembly. When activated, the hydraulic pump uses hydraulic pressure to extend the hydraulic lift cylinders to raise the convertible top, or retract the hydraulic lift cylinders to lower the convertible top. The hydraulic motor/pump assembly is equipped with a thermal circuit breaker. In the event of a concern, the circuit breaker will reset after approximately 5 minutes. The thermal circuit breaker is integral to the hydraulic motor and pump assembly and cannot be serviced separately. In the event of a hydraulic system failure, the convertible top cannot be operated manually.

### Inspection and Verification

1. Verify the customer concern.

2. Visually inspect for obvious signs of mechanical or electrical damage.

**Visual Inspection Chart**

Mechanical	Electrical
<ul style="list-style-type: none"> <li>• Convertible top brackets and frame</li> <li>• Convertible top latches</li> <li>• Hydraulic motor and pump assembly</li> <li>• Hydraulic lift cylinders</li> <li>• Hydraulic lines</li> </ul>	<ul style="list-style-type: none"> <li>• Bussed Electrical Center (BEC) fuse(s):               <ul style="list-style-type: none"> <li>▪ 13 (40A)</li> <li>▪ 51 (10A)</li> </ul> </li> <li>• Hydraulic motor and pump assembly</li> <li>• Convertible top ajar switch</li> <li>• Convertible top switch</li> <li>• Convertible top raise relay</li> <li>• Convertible top lower relay</li> <li>• LH or RH rear power window motor</li> <li>• Smart Junction Box (SJB)</li> <li>• Loose or corroded connections</li> <li>• Wiring harness</li> </ul>

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.

4. **NOTE:** Make sure to use the latest scan tool software release.

If the cause is not visually evident, connect the scan tool to the Data Link Connector (DLC).

5. **NOTE:** The Vehicle Communication Module (VCM) LED prove out confirms power and ground from the [DLC](#) are provided to the [VCM](#).

If the scan tool does not communicate with the [VCM](#) :

- check the [VCM](#) connection to the vehicle.
- check the scan tool connection to the [VCM](#).
- refer to [Section 418-00](#), No Power To The Scan Tool, to diagnose no power to the scan tool.

6. If the scan tool does not communicate with the vehicle:
  - verify the ignition key is in the ON position.
  - verify the scan tool operation with a known good vehicle.
  - refer to [Section 418-00](#) to diagnose no response from the [SJB](#).

7. Carry out the network test.
  - If the scan tool responds with no communication for one or more modules, refer to [Section 418-00](#).
  - If the network test passes, retrieve and record continuous memory DTCs.

8. Clear the continuous DTCs and carry out the self-test diagnostics for the [SJB](#).

9. If the DTCs retrieved are related to the concern, go to the Smart Junction Box (SJB) DTC Chart. For all other DTCs, refer to [Section 419-10](#).

10. If no DTCs related to the concern are retrieved, GO to [Symptom Chart](#).

**DTC Charts**

**Smart Junction Box (SJB) DTC Chart**

DTC	Description	Action
B1402	Driver Power Window Down Switch Circuit Failure	<a href="#">GO to Pinpoint Test A</a> .
B2068	Convertible Top Up Output Circuit Failure	<a href="#">GO to Pinpoint Test A</a> .

B2069	Convertible Top Down Output Circuit Failure	<a href="#">GO to Pinpoint Test A.</a>
B2481	Convertible Top Up/Down Switch Fault	<a href="#">GO to Pinpoint Test A.</a>
B2578	Passenger Power Window Down Switch Circuit Failure	<a href="#">GO to Pinpoint Test A.</a>
All Other DTCs	—	REFER to <a href="#">Section 419-10.</a>

## Symptom Chart

### Symptom Chart

Condition	Possible Sources	Action
<ul style="list-style-type: none"> <li>The convertible top does not raise/lower</li> </ul>	<ul style="list-style-type: none"> <li>Bussed Electrical Center (BEC)</li> <li>Circuitry</li> <li>Convertible top lower relay</li> <li>Convertible top raise relay</li> <li>Convertible top switch</li> <li>Fuse(s)</li> <li>Hydraulic motor and pump assembly</li> <li>LH rear window motor</li> <li>RH rear window motor</li> <li>Smart Junction Box (SJB)</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">GO to Pinpoint Test A.</a></li> </ul>
<ul style="list-style-type: none"> <li>The convertible top does not operate correctly</li> </ul>	<ul style="list-style-type: none"> <li>Convertible top frame bows</li> <li>Convertible top side rails</li> <li>Hydraulic fluid leak</li> <li>Hydraulic lift cylinder</li> <li>Hydraulic motor and pump assembly</li> <li>Low hydraulic fluid</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">GO to Pinpoint Test B.</a></li> </ul>

## Pinpoint Tests

### Pinpoint Test A: The Convertible Top Does Not Raise/Lower

Refer to Wiring Diagrams Cell [103](#), Convertible Top for schematic and connector information.

Refer to Wiring Diagrams Cell [100](#), Power Windows for schematic and connector information.

### Normal Operation

The convertible top switch supplies a ground signal to the Smart Junction Box (SJB) on circuit 2038 (LB/OG) when the convertible top switch is depressed to the lower position, or circuit 2052 (VT/OG) when the convertible top switch is depressed to the raise position. The convertible top system will not operate when the vehicle speed is greater than 5 km/h (3 mph) or if the ignition switch is in the START position. The convertible top hydraulic system uses a 12-volt reversible pump and motor assembly. When the [SJB](#) receives a request to operate the convertible top, the [SJB](#) sends a signal to the front and rear windows to lower the windows to the full down position. The [SJB](#) monitors the status of the rear windows on circuit 2012 (RD/BK) for the right rear window, and circuit 2014 (YE/LB) for the left rear window. When the [SJB](#) detects a full down signal from the RH and LH rear window motors, the convertible top operation is enabled. If the [SJB](#) does not detect a full down signal from the RH and LH rear window motors, the convertible top operation is disabled. When either the convertible top raise relay or the convertible top lower relay is activated, the other relay will remain in its normal state and supplies ground to the hydraulic motor and pump assembly. The convertible top raise and lower relay coils receive voltage at all times from [SJB](#) fuse 51 (10A). The convertible top raise and lower relay contacts receive voltage at all times from [SJB](#) fuse 13 (40A). When the convertible top switch is pressed to the lower position, and the [SJB](#)

detects a full down signal from the LH and RH rear window motors, the [SJB](#) activates the convertible top lower relay by grounding circuit 1174 (WH/RD). When the convertible top lower relay is activated, voltage is supplied to the hydraulic motor and pump through circuit 902 (YE). Ground is supplied to the hydraulic motor and pump assembly through circuit 903 (RD). When the convertible top switch is pressed in the raise position, and the [SJB](#) detects a full down signal from the LH and RH rear window motors, the [SJB](#) activates the convertible top lower relay by grounding circuit 588 (VT). When the convertible top raise relay is activated, voltage is supplied to the hydraulic motor and pump assembly through circuit 903 (RD). Ground is supplied to the hydraulic motor and pump assembly through circuit 902 (YE).

The hydraulic motor/pump assembly is equipped with a thermal circuit breaker. In the event of a concern, the circuit breaker will reset after approximately 5 minutes. The thermal circuit breaker is integral to the hydraulic motor and pump assembly and cannot be serviced separately.

DTC Description	Fault Trigger Conditions
B1402 — Driver Power Window Down Switch Circuit Failure	Short to ground detected by the Driver Seat Module (DSM) during on-demand self test.
B2068 — Convertible Top Up Output Circuit Failure	Short to ground, short to battery or open.
B2069 — Convertible Top Down Output Circuit Failure	Short to ground, short to battery or open.
B2481 — Convertible Top Up/Down Switch Fault	Short to ground.
B2578 — Passenger Power Window Down Switch Circuit Failure	Short to ground detected by the <a href="#">DSM</a> during on-demand self test.


**This pinpoint test is intended to diagnose the following:**

- Bussed Electrical Center (BEC)
- Convertible top raise relay
- Convertible top lower relay
- Convertible top switch
- Fuse(s)
- Hydraulic motor and pump assembly
- LH or RH rear window motor
- [SJB](#)
- Wiring, terminals or connectors

**PINPOINT TEST A: THE CONVERTIBLE TOP DOES NOT RAISE/LOWER**

Test Step	Result / Action to Take
<b>A1 RETRIEVE THE RECORDED DTCs FROM THE <a href="#">SJB</a></b> <ul style="list-style-type: none"> <li>• <b>NOTE:</b> Repair all Vehicle Speed Sensor (VSS) DTCs before proceeding with pinpoint test.</li> <li>• Retrieve the recorded <a href="#">SJB</a> DTCs from the continuous and on-demand self tests.</li> <li>• <b>Are any <a href="#">SJB</a> DTCs recorded?</b></li> </ul>	<p><b>Yes</b> For DTC B2481, GO to <a href="#">A10</a>. For DTC B2068, VERIFY that <a href="#">BEC</a> fuse 51 (10A) is OK. If OK, GO to <a href="#">A12</a>. For DTC B2069, VERIFY that <a href="#">BEC</a> fuse 51 (10A) is OK. If OK, GO to <a href="#">A14</a>. For DTC B1402 or B2578, GO to <a href="#">A21</a>.</p> <p><b>No</b> GO to <a href="#">A2</a>.</p>
<b>A2 CHECK THE VEHICLE SPEED INPUT</b>	

<ul style="list-style-type: none"> <li>• Ignition ON.</li> <li>• Enter the following diagnostic mode on the scan tool: PCM DataLogger.</li> <li>• Monitor the PCM <u>VSS</u> PID.</li> <li>• <b>Does the PID display less than 5 km/h (3 mph)?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">A3</a>.</p> <p><b>No</b> REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual to diagnose the <u>VSS</u>.</p>
<b>A3 CHECK THE <u>SJB</u> CONVERTIBLE TOP SWITCH INPUT</b>	
<ul style="list-style-type: none"> <li>• Enter the following diagnostic mode on the scan tool: <u>SJB</u> PIDs.</li> <li>• Monitor the convertible top switch TOP_UP and TOP_DN <u>SJB</u> PIDs while operating the convertible top switch in the raise and lower positions.</li> <li>• <b>Does the PID status change from OFF to ON for both positions?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">A4</a>.</p> <p><b>No</b> GO to <a href="#">A7</a>.</p>
<b>A4 CHECK THE WINDOW OPERATION</b>	
<ul style="list-style-type: none"> <li>• Raise the front and rear windows to the full up position.</li> <li>• Operate the convertible top switch.</li> <li>• <b>Do the front and rear windows fully open?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">A5</a>.</p> <p><b>No</b> REFER to <a href="#">Section 501-11</a> to diagnose the convertible top drop feature.</p>
<b>A5 CHECK THE REAR WINDOW FULL DOWN INPUTS TO THE <u>SJB</u></b>	
<ul style="list-style-type: none"> <li>• Enter the following diagnostic mode on the scan tool: <u>SJB</u> DataLogger.</li> <li>• Lower the LH and RH rear windows to the full down position.</li> <li>• Monitor the LH and RH rear window LR_DOWN and RR_DOWN <u>SJB</u> PIDs.</li> <li>• <b>Does the PID status display Yes for both PIDs?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">A6</a>.</p> <p><b>No</b> GO to <a href="#">A24</a>.</p>
<b>A6 CHECK FOR CONVERTIBLE TOP MOTOR OPERATION</b>	
<ul style="list-style-type: none"> <li>• Ignition OFF.</li> <li>• Disconnect: <u>SJB</u> C2280C.</li> <li>• Ignition ON.</li> <li>• Connect a fused jumper wire between ground and <u>SJB</u> : <ul style="list-style-type: none"> <li>▪ C2280C-11, circuit 588 (VT), harness side.</li> <li>▪ C2280C-26, circuit 1174 (WH/RD), harness side.</li> </ul> </li> </ul> <div data-bbox="357 1413 762 1787" style="text-align: center;"> <p>N0076731</p> </div> <ul style="list-style-type: none"> <li>• <b>Does the convertible top motor operate in both directions?</b></li> </ul>	<p><b>Yes</b> The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. TEST the system for normal operation.</p> <p><b>No</b> GO to <a href="#">A16</a>.</p>
<b>A7 CHECK CIRCUIT 1205 (BK) AT THE CONVERTIBLE TOP SWITCH FOR AN OPEN</b>	
<ul style="list-style-type: none"> <li>• Ignition OFF.</li> <li>• Disconnect: Convertible Top Switch C9013.</li> <li>• Measure the resistance between convertible top switch C9013-3, circuit 1205 (BK), harness side and ground.</li> </ul>	<p><b>Yes</b> GO to <a href="#">A8</a>.</p> <p><b>No</b> REPAIR the circuit. TEST the system for normal</p>



N0025476

- Is the resistance less than 5 ohms?

operation.


#### A8 CHECK CIRCUITS 2038 (LB/OG) AND 2052 (VT/OG) FOR AN OPEN

- Measure the resistance between convertible top switch C9013, harness side and [SJB](#), harness side using the following chart:

Convertible Top Switch	Circuit	<a href="#">SJB</a>
C9013-6	2038 (LB/OG)	C2280F-16
C9013-7	2052 (VT/OG)	C2280F-15

**Yes**  
GO to [A9](#).

**No**  
REPAIR the circuit(s).  
TEST the system for normal operation.



N0085497

- Are the resistances less than 5 ohms?

#### A9 CHECK THE OPERATION OF THE CONVERTIBLE TOP SWITCH

- Measure the resistance between the convertible top switch pin 7, component side and the convertible top switch pin 3, component side while operating the convertible top switch in the raise position; and between the convertible top switch pin 6, component side and the convertible top switch pin 3, component side while operating the convertible top switch in the lower position.
- Are the resistances less than 5 ohms?

**Yes**  
GO to [A27](#).


**No**  
INSTALL a new convertible top switch. REFER to [Convertible Top Switch](#) in this section. TEST the system for normal operation.

#### A10 CHECK CIRCUITS 2038 (LB/OG) AND 2052 (VT/OG) FOR A SHORT TO GROUND

- Ignition OFF.
- Disconnect: Convertible Top Switch C9013.
- Disconnect: [SJB](#) C2280F.
- Measure the resistance between ground and convertible top switch:
  - C9013-7, circuit 2052 (VT/OG), harness side.
  - C9013-6, circuit 2038 (LB/OG), harness side.

**Yes**  
GO to [A11](#).

**No**  
REPAIR the circuit(s).  
CLEAR the DTCs. REPEAT the self-test.



N0072270

- Are the resistances greater than 10,000 ohms?

#### A11 CHECK THE CONVERTIBLE TOP SWITCH

- Measure the resistance between the convertible top switch pin 7, component side and the convertible top switch pin 3, component side; and between the convertible top switch pin 6, component side and the convertible top switch pin 3, component side.
- Are the resistances greater than 10,000 ohms?

**Yes**  
GO to [A27](#).


**No**  
INSTALL a new convertible top switch. REFER to [Convertible Top Switch](#) in this section. CLEAR the DTCs. REPEAT the self-test.

#### A12 CHECK CIRCUIT 588 (VT) FOR A SHORT TO VOLTAGE

- Ignition OFF.
- Disconnect: [SJB C2280c](#).
- Remove the [BEC](#) convertible top raise relay.
- Ignition ON.
- Measure the voltage between [BEC](#) convertible top raise relay pin 85 and ground.

**Yes**  
REPAIR the circuit. CLEAR the DTCs. REPEAT the self-test.

**No**  
GO to [A13](#).




N0072273

- Is any voltage present?

### A13 CHECK CIRCUIT 588 (VT) FOR A SHORT TO GROUND OR AN OPEN

- Ignition OFF.
- Measure the resistance between **SJB**:
  - C2280c-11, circuit 588 (VT), harness side and **BEC** convertible top raise relay pin 85.
  - C2280c-11, circuit 588 (VT), harness side and ground.



N0076732

- Is the resistance less than 5 ohms between the **SJB** and the **BEC**, and greater than 10,000 ohms between the **SJB** and ground?

#### Yes

CARRY OUT the relay component test for the convertible top raise relay.

Refer to Wiring Diagrams Cell [149](#) for component testing.

If the convertible top raise relay does not pass the component test, INSTALL a new convertible top raise relay. CLEAR the DTCs. REPEAT the self-test. If the convertible top raise relay passes the component test, GO to [A27](#).

#### No

REPAIR the circuit. CLEAR the DTCs. REPEAT the self-test.

### A14 CHECK CIRCUIT 1174 (WH/RD) FOR A SHORT TO VOLTAGE

- Ignition OFF.
- Disconnect: **SJB** C2280c.
- Remove the **BEC** convertible top lower relay.
- Ignition ON.
- Measure the voltage between **BEC** convertible top lower relay pin 85 and ground.


#### Yes

REPAIR the circuit. CLEAR the DTCs. REPEAT the self-test.

#### No

GO to [A15](#).





N0072271

- Is any voltage present?

**A15 CHECK CIRCUIT 1174 (WH/RD) FOR A SHORT TO GROUND OR AN OPEN**


- Ignition OFF.
- Measure the resistance between **SJB**:
  - C2280c-26, circuit 1174 (WH/RD), harness side and **BEC** convertible top lower relay pin 85.
  - C2280c-26, circuit 1174 (WH/RD), harness side and ground.

**Yes**  
 CARRY OUT the relay component test for the convertible top lower relay.

Refer to Wiring Diagrams Cell [149](#) for component testing.

If the convertible top lower relay does not pass the component test, **INSTALL** a new convertible top lower relay. **CLEAR** the DTCs. **REPEAT** the self-test. If the convertible top lower relay passes the component test, **GO** to [A27](#).

**No**  
**REPAIR** the circuit. **CLEAR** the DTCs. **REPEAT** the self-test.



N0076733

- Is the resistance less than 5 ohms between the **SJB** and the **BEC**, and greater than 10,000 ohms between the **SJB** and ground?

#### A16 CHECK THE CONVERTIBLE TOP RELAYS

- Carry out the relay component test for the convertible top raise relay and the convertible top lower relay.  
  
Refer to Wiring Diagrams Cell [149](#) for component testing.
- **Did the convertible top raise relay and the convertible top lower relay pass the relay component test?**

**Yes**  
GO to [A17](#).


**No**  
INSTALL a new convertible top raise relay or convertible top lower relay. TEST the system for normal operation.

#### A17 CHECK FOR VOLTAGE TO THE CONVERTIBLE TOP RELAYS

- Remove the convertible top raise and lower relays.
- Measure the voltage between ground and:
  - **BEC** convertible top lower relay pin 87.
  - **BEC** convertible top raise relay pin 87.

**Yes**  
GO to [A18](#).

**No**  
VERIFY that **BEC** fuse 13 (40A) is OK. If **BEC** fuse 13 (40A) is not OK, GO to [A20](#).



N0072275


- Are the voltages greater than 10 volts?

**A18 CHECK CIRCUIT 1205 (BK) FOR AN OPEN**

- Measure the resistance between ground and:
  - **BEC** convertible top lower relay pin 87a.
  - **BEC** convertible top raise relay pin 87a.

**Yes**  
GO to [A19](#).

**No**  
REPAIR the circuit. TEST the system for normal operation.



N0072276

- Are the resistances less than 5 ohms?

**A19 CHECK CIRCUITS 902 (YE) AND 903 (RD) FOR AN OPEN**

- Ignition OFF.
- Disconnect: Convertible Top Motor C4062.
- Measure the resistance between convertible top motor C4062, harness side and **BEC** relays using the following chart:


Convertible Top Motor	Circuit	<b>BEC</b>
C4062-1	903 (RD)	Convertible Top Lower Relay Pin 30
C4062-2	902 (YE)	Convertible Top Raise Relay Pin 30

**Yes**

INSTALL a new convertible top motor. REFER to [Hydraulic System, Lift Cylinder and Motor](#) in this section. TEST the system for normal operation.

**No**

REPAIR the circuit(s). TEST the system for normal operation.




N0085498

- Are the resistances less than 5 ohms?

**A20 CHECK CIRCUITS 902 (YE) AND 903 (RD) FOR A SHORT TO GROUND**

- Disconnect: Convertible Top Motor C4062.
- Measure the resistance between ground and convertible top motor:
  - C4062-1, circuit 903 (RD), harness side.
  - C4062-2, circuit 902 (YE), harness side.



N0072278

- Are the resistances greater than 10,000 ohms?

**A21 CHECK THE OPERATION OF THE REAR WINDOW MOTORS**


- Raise the LH and RH rear windows to the full up position.
- Ignition OFF.
- Disconnect: **SJB** C2280c.
- Measure the resistance between ground and **SJB**:
  - **DTC B1402**: C2280c-52, circuit 2014 (YE/LB), harness side.
  - **DTC B2578**: C2280c-20, circuit 2012 (RD/BK), harness side.

**Yes**  
INSTALL a new convertible top motor. REFER to [Hydraulic System, Lift Cylinder and Motor](#) in this section. TEST the system for normal operation.

**No**  
REPAIR the circuit(s). TEST the system for normal operation.

**Yes**  
GO to [A22](#).

**No**  
GO to [A27](#).




N0072279

- Is the resistance less than 5 ohms?

### A22 CHECK CIRCUIT 2012 (RD/BK) OR 2014 (YE/LB) FOR A SHORT TO GROUND

- Disconnect: **DTC B1402**: Inline C312.
- Disconnect: **DTC B2578**: Inline C313.
- Measure the resistance between ground and **SJB**:
  - **DTC B1402**: C2280c-52, circuit 2014 (YE/LB), harness side.
  - **DTC B2578**: C2280c-20, circuit 2012 (RD/BK), harness side.




N0072279

- Is the resistance greater than 10,000 ohms?

### A23 CHECK RH REAR WINDOW MOTOR CIRCUIT 2012 (RD/BK) AND LH REAR WINDOW MOTOR CIRCUIT 2012 (RD/BK) FOR A SHORT TO GROUND

- Disconnect: **DTC B1402**: LH Rear Window Motor C3118.
- Disconnect: **DTC B2578**: RH Rear Window Motor C3119.
- Measure the resistance between ground and **SJB**:
  - **DTC B1402**: C312-1, circuit 2012 (RD/BK), window motor side.
  - **DTC B2578**: C313-1, circuit 2012 (RD/BK), window motor side.



N0072590

**Yes**  
GO to [A23](#).

**No**  
REPAIR the circuit(s).  
CLEAR the DTCs. REPEAT the self-test.


**Yes**  
INSTALL a new LH or RH rear window motor as necessary. REFER to [Section 501-11](#). CLEAR the DTCs. REPEAT the self-test.

**No**  
REPAIR the circuit(s).  
CLEAR the DTCs. REPEAT the self-test.

- Is the resistance greater than 10,000 ohms?

#### A24 CHECK THE INPUTS TO THE **SJB**

- Ignition OFF.
- Disconnect: Inline C312.
- Disconnect: Inline C313.
- Ignition ON.
- Enter the following diagnostic mode on the scan tool: **SJB** DataLogger.
- Monitor the LH and RH rear window LR\_DOWN and RR\_DOWN **SJB** PIDs while connecting a fused jumper wire between ground and inline:
  - C312-1, circuit 2014 (YE/BK), **SJB** side.
  - C313-1, circuit 2012 (RD/BK), **SJB** side.



N0076734


- Does the PID status display Yes for both PIDs?

**Yes**  
GO to [A26](#).

**No**  
GO to [A25](#).

#### A25 CHECK CIRCUIT 2012 (RD/BK) OR CIRCUIT 2014 (YE/LB) FOR AN OPEN

- Disconnect: **SJB** 2280C.
- Measure the resistance between **SJB**:
  - C2280C-20, circuit 2012 (RD/BK), harness side and inline C313-1, circuit 2012 (RD/BK), **SJB** side.
  - C2280C-52, circuit 2014 (YE/LB), harness side and inline C312-1, circuit 2014 (YE/LB), **SJB** side.



N0073522

- Are the resistances less than 5 ohms?

**Yes**  
GO to [A27](#).


**No**  
REPAIR the circuit(s).  
TEST the system for normal operation.

#### A26 CHECK RH REAR WINDOW MOTOR CIRCUIT 2012 (RD/BK) AND LH REAR WINDOW MOTOR CIRCUIT 2012 (RD/BK) FOR AN OPEN

- Disconnect: RH Rear Window Motor C3118.
- Disconnect: LH Rear Window Motor C3119.
- Measure the resistance between rear window motor:
  - **RH**: C3119-5, circuit 2012 (RD/BK), harness side and inline C313-1, circuit 2012 (RD/BK), window motor side.
  - **LH**: C3118-5, circuit 2012 (RD/BK), harness side and inline

**Yes**  
INSTALL a new LH or RH rear window motor. REFER to [Section 501-11](#). TEST the system for normal operation.

C312-1, circuit 2012 (RD/BK), window motor side.



N0073523

- Are the resistances less than 5 ohms?

**No**  
REPAIR the circuit(s).  
TEST the system for normal operation.

**A27 CHECK FOR CORRECT SJB OPERATION**

- Disconnect all the SJB connectors.
- Check for:
  - corrosion.
  - pushed-out pins.
- Connect all the SJB connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.
- **Is the concern still present?**

**Yes**  
INSTALL a new SJB.  
REFER to [Section 419-10](#).  
CLEAR the DTCs. REPEAT the self-test.

**No**  
The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the self-test.

**Pinpoint Test B: The Convertible Top Does Not Operate Correctly**

Refer to Wiring Diagrams Cell [103](#), Convertible Top for schematic and connector information.

**Normal Operation**

The convertible top hydraulic system uses a 12-volt reversible pump and motor assembly. When active, the pump uses hydraulic pressure to extend the hydraulic lift cylinders to raise the convertible top, or retract the hydraulic lift cylinders to lower the convertible top. The convertible top assembly is a floating frame, Z-fold design. The main pivot brackets are attached to the body, and the convertible top frame side rails expand or fold when the convertible top is raised or lowered. The convertible top frame bows attach to the convertible top frame side rails and provide tension for the convertible top material.

**This pinpoint test is intended to diagnose the following:**

- Convertible top frame bows
- Convertible top side rails
- Hydraulic fluid leak
- Hydraulic lift cylinders
- Hydraulic motor/pump assembly
- Low hydraulic fluid

**PINPOINT TEST B: THE CONVERTIBLE TOP DOES NOT OPERATE CORRECTLY**

Test Step	Result / Action to Take



<b>B1 CHECK THE HYDRAULIC FLUID LEVEL</b>	
<ul style="list-style-type: none"> <li>• Lower the convertible top.</li> <li>• Gain access to the hydraulic motor and pump assembly.</li> <li>• <b>NOTE:</b> Make sure that the hydraulic lift cylinders are fully retracted before checking the hydraulic fluid level.</li> <li>• Inspect the hydraulic reservoir and check the hydraulic fluid level.</li> <li>• <b>Is the hydraulic fluid level at the "+" sign that is molded into the hydraulic reservoir?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">B4</a>.</p> <p><b>No</b> GO to <a href="#">B2</a>.</p>
<b>B2 CHECK THE HYDRAULIC SYSTEM FOR LEAKS</b>	
<ul style="list-style-type: none"> <li>• Inspect all hydraulic fittings and hoses for hydraulic fluid leaks.</li> <li>• <b>Are any hydraulic fluid leaks present?</b></li> </ul>	<p><b>Yes</b> REPAIR the leaking hydraulic fitting or INSTALL a new hydraulic hose as necessary. BLEED the hydraulic system. REFER to <a href="#">System Bleeding</a> in this section. TEST the system for normal operation.</p> <p><b>No</b> GO to <a href="#">B3</a>.</p>
<b>B3 FILL THE HYDRAULIC SYSTEM</b>	
<ul style="list-style-type: none"> <li>• <b>NOTE:</b> The hydraulic fluid level should be at the "+" sign that is molded into the hydraulic reservoir.</li> <li>• Add hydraulic fluid to the hydraulic fluid reservoir.</li> <li>• Operate the convertible top system.</li> <li>• <b>Does the convertible top system operate correctly?</b></li> </ul>	<p><b>Yes</b> The concern is not present at this time. RETURN the vehicle to the customer.</p> <p><b>No</b> BLEED the hydraulic system. REFER to <a href="#">System Bleeding</a> in this section. TEST the system for normal operation.</p>
<b>B4 CHECK THE CONVERTIBLE TOP LINKAGE</b>	
<ul style="list-style-type: none"> <li>• Remove the hydraulic lift cylinder bolts and disconnect the hydraulic lift cylinders from the convertible top linkage.</li> <li>• <b>NOTE:</b> The convertible top is not adjustable. If the convertible top frame is damaged or requires adjustment, the damaged components must be replaced.</li> <li>• Manually operate the convertible top assembly up and down while observing the convertible top linkage.</li> <li>• <b>Does the linkage operate smoothly without binding?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">B5</a>.</p> <p><b>No</b> INSTALL new components as necessary. REFER to <a href="#">Convertible Top Bows</a> or <a href="#">Convertible Top Side Rail</a> in this section. TEST the system for normal operation.</p>
<b>B5 CHECK THE HYDRAULIC LIFT CYLINDERS</b>	
<ul style="list-style-type: none"> <li>• Operate the hydraulic system using a 12-volt fused (40A) power source.</li> <li>• <b>Do the hydraulic lift cylinders extend and retract fully and evenly?</b></li> </ul>	<p><b>Yes</b> GO to <a href="#">B6</a>.</p> <p><b>No</b> BLEED the hydraulic system. REFER to <a href="#">System Bleeding</a> in this section. If concern is still present after bleeding the hydraulic system, INSTALL a new hydraulic lift cylinder. REFER to <a href="#">Hydraulic System, Lift Cylinder and Motor</a> in this section. TEST the system for normal operation.</p>
<b>B6 BLEED THE HYDRAULIC SYSTEM</b>	
<ul style="list-style-type: none"> <li>• Bleed the hydraulic system. Refer to</li> </ul>	<p><b>Yes</b></p>

[System Bleeding](#) in this section.

- Operate the convertible top system upward and downward 3 times.
- **Does the convertible top system operate correctly?**

The concern is not present at this time. RETURN the vehicle to the customer.

**No**

INSTALL a new motor and pump assembly. REFER to [Hydraulic System, Lift Cylinder and Motor](#) in this section. TEST the system for normal operation.

---