

DU: Intake Air Temperature 2 (IAT2) Sensor

← [DU: Introduction](#)

DU1 CHECK FOR DIAGNOSTIC TROUBLE CODES (DTCS)

Are DTCs P0097, P0098, P0127, P1114, or P1115 present?

| Yes | No |
|--|--|
| For DTCs P0097 or P1114, GO to DU4 . For DTCs P0098 or P1115, GO to DU2 . For DTC P0127, GO to DU6 . | For all others, GO to Section 4, Diagnostic Trouble Code (DTC) Charts and Descriptions . |

DU2 CHECK FOR AN OPPOSITE SIGNAL TO THE PCM

- The DTC indicates the sensor signal is greater than the self-test maximum.
- IAT2 Sensor connector disconnected.
- Ignition ON, engine OFF.
- Connect a 5 amp fused jumper wire between the following:

| Point A IAT2 Sensor Connector, Harness Side | Point B IAT2 Sensor Connector, Harness Side |
|---|---|
| IAT2 - Pin 1 | SIGRTN - Pin 2 |

- Access the PCM and monitor the IAT2 PID.

Is the voltage less than 0.2 V?

| Yes | No |
|---|-----------------------------|
| INSTALL a new IAT2 sensor. REFER to the Workshop Manual Section 303-14, Electronic Engine Controls. CLEAR the DTCs. REPEAT the self-test. | GO to DU3 . |

DU3 CHECK THE SENSOR SIGNAL FOR A SHORT TO VREF

- Ignition OFF.
- Remove the jumper wire(s).
- PCM connector disconnected.
- Measure the resistance between:

| (+) PCM Connector, Harness Side | (-) PCM Connector, Harness Side |
|-----------------------------------|-----------------------------------|
| IAT2 - Pin E27 | VREF - Pin B40, E57 |

Is the resistance greater than 10K ohms?

| Yes | No |
|------------------------------|---|
| GO to DU10 . | REPAIR the short circuit to VREF. CLEAR the |

| |
|-----------------------------|
| DTCs. REPEAT the self-test. |
|-----------------------------|

DU4 DTC P1114: SIMULATE AN OPPOSITE SIGNAL TO THE PCM

- The DTC indicates the sensor signal is less than the self-test minimum.
- IAT2 Sensor connector disconnected.
- Ignition ON, engine OFF.
- Access the PCM and monitor the IAT2 PID.

Is the voltage greater than 4.2 V?

| Yes | No |
|---|-----------------------------|
| INSTALL a new IAT2 sensor. REFER to the Workshop Manual Section 303-14, Electronic Engine Controls. CLEAR the DTCs. REPEAT the self-test. | GO to DU5 . |

DU5 CHECK THE SENSOR SIGNAL FOR A SHORT TO GROUND

- Ignition OFF.
- PCM connector disconnected.
- Measure the resistance between:

| (+) PCM Connector, Harness Side | (-) PCM Connector, Harness Side |
|-----------------------------------|-----------------------------------|
| IAT2 - Pin E27 | SIGRTN - Pin B41, E58, T41 |

- Measure the resistance between:

| (+) PCM Connector, Harness Side | (-) 12 Volt Vehicle Battery |
|-----------------------------------|-------------------------------|
| IAT2 - Pin E27 | Negative terminal |

Is the resistance greater than 10K ohms?

| Yes | No |
|------------------------------|---|
| GO to DU10 . | REPAIR the short circuit. CLEAR the DTCs. REPEAT the self-test. |

DU6 DTC P0127: CHECK CHARGE AIR COOLER PUMP (CAC) OPERATION

- Enter output test mode. Refer to Section 2, [Output Test Mode \(OTM\)](#).
- Command the outputs ON.
- Command the outputs OFF.
- Exit output test mode.

Does the CAC pump run?

| Yes | No |
|-----------------------------|---|
| GO to DU7 . | DIAGNOSE the CAC pump. GO to KP9 . |

DU7 CHECK THE CHARGE AIR COOLER (CAC) SYSTEM

- Check the CAC system for low fluid level, cracked, blocked or misrouted coolant lines, cracked or blocked heat exchanger.

Is a concern present?

| Yes | No |
|--|-----------------------------|
| REFER to the Workshop Manual Section 303-03B, Supercharger Cooling, to DIAGNOSE a loss of coolant. REPAIR as necessary. CLEAR the DTCs. REPEAT the self-test. | GO to DU8 . |

DU8 SIMULATE THE HIGH IAT2 SIGNAL TO THE PCM

- Ignition ON, engine OFF.
- Access the PCM and monitor the IAT2 PID.
- Observe the PID while disconnecting the IAT2 sensor.

Is the voltage greater than 4.2 V?

| Yes | No |
|-----------------------------|------------------------------|
| GO to DU9 . | GO to DU10 . |

DU9 SIMULATE THE LOW IAT2 SIGNAL TO THE PCM

- Ignition OFF.
- IAT2 Sensor connector disconnected.
- Connect a 5 amp fused jumper wire between the following:

| Point A IAT2 Sensor Connector, Harness Side | Point B IAT2 Sensor Connector, Harness Side |
|---|---|
| IAT2 - Pin 1 | SIGRTN - Pin 2 |

- Ignition ON, engine OFF.
- Access the PCM and monitor the IAT2 PID.

Is the voltage less than 0.2 V?

| Yes | No |
|---|------------------------------|
| CONNECT the sensor and GO to Section 6 , Reference Values. COMPARE the IAT2 PID to reference values under different road test conditions. If the sensor is not in range, INSTALL a new IAT2 sensor. REFER to the Workshop Manual Section 303-14, Electronic Engine Controls. CLEAR the DTCs. REPEAT the self-test. | GO to DU10 . |

DU10 CHECK FOR CORRECT PCM OPERATION

- Disconnect all the PCM connectors.
- Visually inspect for:
 - pushed out pins
 - corrosion
- Connect all the PCM connectors and make sure they seat correctly.
- Carry out the PCM self-test and verify the concern is still present.

Is the concern still present?

| Yes | No |
|--|--|
| INSTALL a new PCM. REFER to Section 2, Flash Electrically Erasable Programmable Read Only Memory (EEPROM) , Programming the VID Block for a Replacement PCM. | The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. |
