

HM: Secondary Air Injection (AIR) System [HM: Introduction](#)**HM1 CHECK FOR DIAGNOSTIC TROUBLE CODES (DTC)**

Are DTCs P0410, P0412, P0491, P2257, P2258, or P2448 present?

Yes	No
GO to HM2 .	For all others, GO to Section 4, Diagnostic Trouble Code (DTC) Charts and Descriptions .

HM2 VISUALLY INSPECT THE SECONDARY AIR SYSTEM COMPONENTS AND HOSES

- Visually inspect the secondary AIR system components, connectors and hoses for:
 - damaged hoses
 - obstructions
 - exhaust damage
 - restricted secondary AIR pump inlet
 - water or ice

Are the secondary AIR system components and hoses OK?

Yes	No
GO to HM3 .	REPAIR as necessary. CLEAR the DTCs. REPEAT the self-test.

HM3 CHECK THE VPWR VOLTAGE TO THE SECONDARY AIR RELAY

- Secondary AIR relay removed.
- Ignition ON, engine OFF.
- Measure the voltage between:

(+) Secondary AIR Relay Connector, Harness Side	(-)
VPWR - Pin 85	Ground
B+ - Pin 30	Ground

Are the voltages greater than 10 V?

Yes	No
GO to HM4 .	REPAIR the open circuit. CLEAR the DTCs. REPEAT the self-test.

HM4 CHECK THE SECONDARY AIR RELAY

- Ignition OFF.

- Carry out the relay component test. Refer to the Wiring Diagrams Cell 149 Component Testing.

Does the relay pass the component test?

Yes	No
GO to HM5 .	INSTALL a new secondary AIR relay. CLEAR the DTCs. REPEAT the self-test.

HM5 CHECK THE SECONDARY AIR PUMP GROUND CIRCUIT FOR AN OPEN CIRCUIT IN THE HARNESS

- Secondary AIR Pump Motor connector disconnected.
- Measure the resistance between:

(+) Secondary Air Pump Connector, Harness Side	(-)
AIR_GND - Pin 1	Ground

Is the resistance less than 5 ohms?

Yes	No
GO to HM6 .	REPAIR the open circuit. CLEAR the DTCs. REPEAT the self-test.

HM6 CHECK THE SECONDARY AIR PUMP CIRCUIT(S) FOR AN OPEN IN THE HARNESS

- Measure the resistance between:

(+) Secondary AIR Relay Connector, Harness Side	(-) Secondary Air Pump Connector, Harness Side
AIR_PWR - Pin 87	AIR_PWR - Pin 2

Is the resistance less than 5 ohms?

Yes	No
GO to HM7 .	REPAIR the open circuit. CLEAR the DTCs. REPEAT the self-test.

HM7 CHECK THE SECONDARY AIR CIRCUIT(S) FOR AN OPEN IN THE HARNESS

- PCM connector disconnected.
- Measure the resistance between:

(+) PCM Connector, Harness Side	(-) Secondary AIR Relay Connector, Harness Side
AIR - Pin B1	AIR - Pin 86
AIRM - Pin B50	AIR_PWR - Pin 87

Are the resistances less than 5 ohms?

Yes	No

GO to [HM8](#).

REPAIR the open circuit. CLEAR the DTCs.
REPEAT the self-test.

HM8 CHECK THE SECONDARY AIR MONITOR CIRCUIT AND THE SECONDARY AIR PUMP VOLTAGE CIRCUIT FOR A SHORT TO GROUND

- Measure the resistance between:

(+) PCM Connector, Harness Side	(-)
AIRM - Pin B50	Ground
AIR - Pin B1	Ground

Are the resistances greater than 10K ohms?

Yes	No
GO to HM9 .	REPAIR the short circuit. CLEAR the DTCs. REPEAT the self-test.

HM9 CHECK THE SECONDARY AIR MONITOR CIRCUIT AND THE SECONDARY AIR PUMP VOLTAGE CIRCUIT FOR A SHORT TO VOLTAGE

- Ignition ON, engine OFF.
- Measure the voltage between:

(+) PCM Connector, Harness Side	(-)
AIRM - Pin B50	Ground
AIR - Pin B1	Ground

Is any voltage present?

Yes	No
REPAIR the short circuit. CLEAR the DTCs. REPEAT the self-test.	GO to HM10 .

HM10 MEASURE THE VACUUM AT THE SECONDARY AIR SOLENOID VALVE

NOTICE: Running the secondary AIR pump with OTM longer than 2 minutes may overheat and damage the secondary AIR pump. Refer to Section 2, {Output Test Mode}.

- Ignition OFF.
- Secondary AIR relay installed.
- Secondary AIR Solenoid connector connected.
- PCM connector connected.
- Ignition ON, engine OFF.
- Connect a vacuum gauge to the control vacuum outlet at the secondary AIR valve.
- Enter output test mode. Refer to Section 2, [Output Test Mode \(OTM\)](#).
- Command the outputs ON.
- Observe the vacuum gauge reading at the secondary AIR valve.
- Command the outputs OFF.

- Exit output test mode.

Is vacuum present at the secondary AIR diverter valve?

Yes	No
GO to HM11 .	INSTALL a new secondary AIR valve. REFER to the Workshop Manual Section 303-08A, Engine Emission Control. CLEAR the DTCs. REPEAT the self-test.

HM11 CHECK THE SECONDARY AIR PUMP OPERATION

- Enter output test mode. Refer to Section 2, [Output Test Mode \(OTM\)](#).
- Disconnect the inlet hose from the secondary AIR valve.
- Command the outputs ON.
- Place your hand over the secondary AIR valve inlet hose.
- Command the outputs OFF.
- Exit output test mode.

Is there any air flow from the secondary AIR inlet valve hose?

Yes	No
INSTALL a new secondary AIR valve. REFER to the Workshop Manual Section 303-08A, Engine Emission Control. CLEAR the DTCs. REPEAT the self-test.	INSTALL a new secondary AIR pump. REFER to the Workshop Manual Section 303-08A, Engine Emission Control. CLEAR the DTCs. REPEAT the self-test.
