

Convertible Top Bows

Removal and Installation

1. Remove the convertible top headliner. For additional information, refer to [Convertible Top Headliner](#) in this section.
2. Remove the screws and the appropriate convertible top frame bow(s).
3. **NOTE:** Manually operate the convertible top frame before installing the headliner, to be sure the frame operates smoothly, without binding.

To install, reverse the removal procedure.
