

Convertible Top Side Rail

Removal and Installation

1. Remove the convertible top headliner. For additional information, refer to [Convertible Top Headliner](#) in this section.
2. Remove the screws and the side rail(s) from the convertible top frame bows.
3. **NOTE:** Manually operate the convertible top frame before installing the headliner, to be sure the frame operates smoothly, without binding.

To install, reverse the removal procedure.

- Make sure the door glass and quarter glass correctly seal against the convertible top side rail. If adjustment is necessary, refer to [Section 501-11](#).
-