









Torque Wrench Adapter Formulas



TORQUE FORMULA LEGEND

T_s = Torque wrench setting
 T_d = Fastener torque desired

A = Torque wrench length
 B = Torque adapter length