

## Brake Caliper Anchor Plate

### Material

Item	Specification
Metal Brake Parts Cleaner PM-4-A or PM-4-B (US); CPM-4 (Canada)	—

### Removal

1. Remove the brake pads. For additional information, refer to [Brake Pads](#) in this section.
2. Remove the 2 brake caliper anchor plate bolts and the brake caliper.
  - Discard the bolts.

### Installation

1. **NOTICE:** In order for the brake caliper anchor plate bolts to attain the proper clamp load when installed, the residual thread lock compound must be cleaned out of the bolt threads of the anchor plate.

Use the specified brake parts cleaner to clean any residual thread lock compound, and any other foreign material, from the threads of the brake caliper anchor plate.

2. Position the brake caliper anchor plate and install 2 new anchor plate bolts.
    - Tighten to 103 Nm (76 lb-ft).
  3. Install the brake pads. For additional information, refer to [Brake Pads](#) in this section.
-