

Piston To Cylinder Bore Clearance

NOTE: Refer to the appropriate Section 303-01 for the specification.

1. Subtract the piston diameter from the cylinder bore diameter to find the piston-to-cylinder bore clearance.
-