Valve Spring Installed Length

NOTE: Refer to the appropriate Section 303-01 for the specification.

1. Measure the installed length of each valve spring.

