Hydraulic Lash Adjuster

Material

Item	Specification
Motorcraft® SAE 5W-20 Premium Synthetic Blend Motor Oil XO-5W20-QSP (US); Motorcraft® SAE 5W-20 Super Premium Motor Oil CXO-5W20-LSP12 (Canada); or equivalent	WSS- M2C930-A

Removal and Installation

- 1. Remove the camshafts. For additional information, refer to <u>Valve Train Components Exploded View</u>, <u>Camshaft LH</u> and <u>Camshaft RH</u> in this section.
- 2. Remove the remaining roller followers from the cylinder head being serviced.
- 3. *NOTICE:* If the components are to be reinstalled, they must be installed in their original positions. Mark the components for installation into their original locations. Failure to follow these instructions may result in engine damage.

Remove the hydraulic lash adjusters that are being serviced.

- 4. Inspect the hydraulic lash adjusters. For additional information, refer to Section 303-00.
- 5. **NOTE:** Lubricate each of the hydraulic lash adjusters with clean engine oil prior to installation.

To install, reverse the removal procedure.