Thermostat — 5.4L (4V)

Material

Item	Specification
Motorcraft® Premium Gold Engine Coolant with Bittering Agent (bittered in US only) VC-7-B (US); CVC-7-A (Canada); or equivalent (yellow color)	WSS-M97B51- A1

Removal and Installation

- 1. Drain the engine cooling system. For additional information, refer to <u>Cooling System Draining</u>, <u>Filling and Bleeding</u> in this section.
- 2. Remove the 2 bolts and position aside the thermostat housing cover and hose assembly.
 - To install, tighten to 10 Nm (89 lb-in).
- 3. Remove the O-ring seal and the thermostat.
 - Discard the O-ring seal.
- 4. To install, reverse the removal procedure.
 - Lubricate the new O-ring seal with clean engine coolant.
- 5. Fill and bleed the cooling system. For additional information, refer to <u>Cooling System Draining</u>, <u>Filling and Bleeding</u> in this section.