


Intake Air System Components — Exploded View, 4.6L (3V)


GT 4.6L (3V)



Item	Part Number	Description
1	9C632	Air Cleaner (ACL) outlet pipe clamp
2	6758	Crankcase vent tube
3	9B659	ACL outlet pipe
4	9C632	ACL outlet pipe clamp
5	14A464	Mass Air Flow (MAF) sensor electrical connector
6	9661	ACL cover (part of 9A600)

7	9601	ACL element
8	W505427	ACL assembly bolt
9	9A600	ACL assembly
10	9P686	ACL assembly grommet

Bullitt 4.6L (3V)



N0080257

Item	Part Number	Description
1	9C632	Air Cleaner (ACL) outlet pipe clamp
2	6758	Crankcase vent tube
3	9F805	ACL outlet pipe
4	9C632	ACL outlet pipe clamp
5	14A464	Mass Air Flow (MAF) sensor electrical connector

6	—	ACL pipe seal (part of 9600)
7	W500224	ACL pipe seal bolts (2 required)
8	9C632	ACL element clamp
9	9601	ACL element
10	W505427	ACL bolt
11	N620480	ACL nut
12	9600	ACL housing
13	9P686	ACL assembly grommets

1. For additional information, refer to the procedures in this section.
-