

Brake Shift Interlock Actuator

Removal and Installation

1. **NOTE:** The Brake Shift Interlock Actuator (BSIA) is not serviced separately. If a new [BSIA](#) is required, install a new transmission selector lever assembly.

For additional information, refer to [Selector Lever](#) in this section.
