
Heating Ventilation Air Conditioning (HVAC) Module



Item	Part Number	Description
1	W505944	HVAC module screw (4 required)
2	19980	HVAC module

Removal and Installation

- 1. Remove the center instrument panel finish panel. For additional information, refer to <u>Section 501-12</u>.
- 2. Remove the 4 HVAC module screws.
- 3. Remove the HVAC module.
- 4. **NOTE:** Be sure that all HVAC module electrical connectors are securely fastened before installing the center instrument panel finish panel.

To install, reverse the removal procedure.