


## Instrument Cluster (IC) Lens

### Removal and Installation

1. Remove the Instrument Cluster (IC). For additional information, refer to [Instrument Cluster \(IC\)](#) in this section.
2. Release the retaining tabs and remove the **IC** lens.



3. To install, reverse the removal procedure.
-