


Quarter Panel Speaker



| Item | Part Number | Description |
|------|-------------|---|
| 1 | W709996 | Quarter panel speaker screws (4 required) |
| 2 | 18808 | Quarter panel speaker |
| 3 | — | Quarter panel speaker electrical connector (part of 14A005) |
| 4 | W701930 | Quarter panel speaker mounting bracket screws (3 required) |

Removal and Installation

1. Remove the quarter trim panel. For additional information, refer to [Section 501-05](#).
2. Remove the 4 screws and the quarter panel speaker.
 - Disconnect the electrical connector.
3. To install, reverse the removal procedure.

