

## Quarter Window Trim Panel

### Removal and Installation

1. **NOTE:** On the coupe, install the front locating hook, then snap the A-pillar trim panel in place, working rearward.

Remove the 2 A-pillar trim panels. For additional information, refer to [A-Pillar Trim Panel](#) in this section.

2. Remove the rear quarter trim panel. For additional information, refer to [Quarter Trim Panel — Coupe](#) in this section.
  3. Open the garment hook cover. Remove the bolt and garment hook.
  4. Remove the upper front safety belt anchor bolt cover and bolt.
    - To install, tighten to 48 Nm (35 lb-ft).
  5. Remove the quarter window trim panel, by pulling outward.
  6. To install, reverse the removal procedure.
-