


## Interior Rear View Mirror

### Special Tool(s)

 ST1793-A	Installer, Rear View Mirror 501-025 (T94P-17700-AH)
---	--



Item	Part Number	Description
1	17700	Interior rear view mirror


### Removal

**NOTICE:** The interior rear view mirror is of the break-away design. Excessive force in any direction may cause damage to the mirror or the windshield.

1. Position the interior rear view mirror in the full up position.
2. Insert a suitable tool between the bottom of the mirror mount and bracket. Push upward on the tool until the mirror mount is released from the bracket.

### Installation

1. Place the interior rear view mirror on the windshield bracket.
2. Using the Rear View Mirror Installer, press the interior rear view mirror in place until fully seated.



N0003347

---