


Window Control Switch

NOTE: LH side shown, RH side similar.

NOTE: Coupe shown, convertible similar.



N0052764

Item	Part Number	Description
1	241A22	Door panel switch plate
2	—	Window control switch electrical connector (part of 14630/14631)
3	14529	Window control switch

Removal and Installation

1. **NOTICE:** Use a shop towel or similar material between the tool and the door trim panel or damage to the door trim panel may occur.

Release the clip and remove the door panel switch plate.

- Disconnect the electrical connector.
2. Release the tabs and remove the window control switch.
 3. To install, reverse the removal procedure.
-