


## Door Lock Control Switch

### Removal and Installation

1. Remove the interior door handle. For additional information, refer to [Interior Door Handle](#) in this section.
2. Remove the door lock control switch from the interior door handle.



3. To install, reverse the removal procedure.
-