## **Interior Door Handle**

## **Removal and Installation**

- 1. Remove the door trim panel. For additional information, refer to Section 501-05.
- 2. Remove the interior door handle from the door trim panel.
- 3. To install, reverse the removal procedure.