
ND: Engine RPM\Vehicle Speed Limiter Reached

 [ND: Introduction](#)**ND1 DTCS P0219, P0297 OR P1270: EXCESSIVE ENGINE RPM OR VEHICLE SPEED**

- P0219 (engine over speed), P0297 (vehicle over speed) or P1270 DTCs indicate the vehicle was operated in a manner which caused the engine or vehicle speed to exceed a calibrated limit.
 - Excessive engine RPM in NEUTRAL or operated in the wrong transmission gear.
 - Excessive wheel slippage (water, ice, mud or snow).
 - Vehicle driven at a high rate of speed.

Was the vehicle operating in any of the above conditions?

Yes	No
The on-board diagnostics (OBD) system is OK. RETURN the vehicle to customer with information about the DTC.	REFER to Section 3, No Diagnostic Trouble Codes (DTCs) Present Symptom Chart Index . If there are no other symptoms, RETURN the vehicle to the customer with information about the DTC.
