
NC: Ignition Engine Speed Input Circuit

[← NC: Introduction](#)**NC1 CONTINUOUS MEMORY DTC P0320: ERRATIC IGNITION**

- Verify all 2-way radio installations. Carefully follow the manufacturer's installation instructions regarding the routing of the antenna and voltage leads.

Is a concern present?

Yes	No
REPAIR as necessary. CLEAR the DTCs. REPEAT the self-test.	GO to NC2 .

NC2 NO START CONCERN**Is the customer complaint a no start?**

Yes	No
GO to Pinpoint Test A .	GO to NC3 .

NC3 INTERMITTENT CONDITION**Is this an intermittent condition?**

Yes	No
GO to Pinpoint Test Z .	GO to Pinpoint Test JD .
