



- ▣ Connector
- ▣ Grommet

| Item | Part Number | Description |
|------|-------------|---|
| 1 | 12B637 | Wiring harness - Engine control sensor and fuel charge |
| 2 | 14290 | Wiring harness - Dash panel to headlamp junction |
| 3 | 14305 | Wiring harness - Alternator rectifier system |
| 4 | 14B060 | Wiring harness - Starter motor relay and battery ground |
| 5 | 14334 | Wiring harness - Interior lamps (coupe) |
| | 14335 | Wiring harness - Interior illumination (Convertible) |
| 6 | 14401 | Wiring harness - Main |
| 7 | 14630 | Wiring harness - Window regulator, right front door |
| 8 | 14631 | Wiring harness - Window regulator, left front door |
| 9 | 14A005 | Wiring harness - Body main |
| 10 | 14A576 | Wiring harness - Safety belt switch, Extension |
| 11 | 14A699 | Wiring harness - Power seats (with lumbar) |
| 12 | 18B574 | Wiring harness - Fan motor |
| 13 | 19B113 | Wiring harness - Radio amplifier |
| 14 | 19B516 | Wiring harness - Luggage compartment |
| 15 | 13A444 | Wiring harness - Rear license plate lamp |
| 16 | 13A412 | Wiring harness - Rear lamp extension jumper |
| 17 | 14A017 | Wiring harness - Back window regulator |
| 20 | 14407 | Wiring harness - Brake control speed sensor |
| 21 | 12638 | Wiring harness - Pedal sensor jumper |
| 22 | 12A690 | Wiring harness - Engine control sensor extension |
| 23 | 14C585 | Wiring harness - Visor and mirror |
| 24 | 14A411 | Wiring harness - Canister vent jumper |