


LF TIRE PRESSURE SENSOR

LR TIRE PRESSURE SENSOR



SMART
JUNCTION
BOX (SJB)
11-3
151-20

RF TIRE PRESSURE SENSOR

RR TIRE PRESSURE SENSOR